



NorthrockParts.com

888-634-4289

An iBuy Stores Company

VIBRATOR HEAD PARTS LIST

NO.	DESCRIPTION	3/4" HEAD	1" HEAD	1 1/4" HEAD	1 1/2" HEAD	1 3/4" HEAD	2" HEAD	2 1/2" HEAD	QTY. REQ'D
		PART No.	PART No.	PART No.	PART No.	PART No.	PART No.	PART No.	
1	NOSEPIECE	100A75	100B1	100C12	100D15	100E17	100F2	100G25	1
2	BEARING (NOSE END)	140F4	140A608	140A000	140A201	140A301	140A302	140A205	2
3	SHELL	105A75	105B1	105C12	105D15	105E17	105F2	105G25	1
4	ROTOR	Part no. is dependent on appropriate style and size.*							1
5	BEARING (CASING ADAPTER END)	140F4	140A608	140A000	140A201	140A203	140A204	140A205	2
6	SEAL CARRIER ASEMBLY	110A1	125H1	125J1	125K1	125L1	125M1	125N1	1
7	CORE ADAPTER	Part no. is dependent on appropriate style and size.*							1
8	CASING ADAPTER	Part no. is dependent on appropriate style and size.*							1

* Call for more information.

NorthrockParts.com
 888-634-4289
 An iBuy Stores Company